


UBIBOT

# LoRa Door Magnetic Sensor

## DC1-DM

User Manual

## PACKAGE LIST



① Device x 1



② 3M Adhesive x 1




③ Eject Pin x 1

---

## INTRODUCTION

### 1. Basic Features Introduction




## 2. Device Operations

- Send data** Press the button once, the green device status indicator will flash, and the device will then send data.
- Setup Mode** Press and hold the button for about 3 seconds until the device status indicator flashes red and green alternately. Release at this time to enter the setup mode.
- Reset to Default Settings** Press and hold the function button for about 8 seconds until the red device status indicator blinks, then release the button to restore factory settings.

## DEVICE SETUP

Download the App at [www.ubibot.com/setup](http://www.ubibot.com/setup) or search 'UbiBot Connect' on the App Store or Google Play.


Launch the App and log in. In the app, select the LoRa Gateway and go to the Glance page. Tap "+" to start adding your node device. Then please follow the in-app instructions to complete the setup. You can also view the demonstration video at [www.ubibot.com/setup](http://www.ubibot.com/setup) for step by step guidance.



Via the app and web console (<http://console.ubibot.com>), you are able to view the readings as well as configure your device, such as create alert rules, set data sync interval, etc.

# Device Installation


1. Insert the batteries into the transmitter and mount it onto the base plate.



2. Attach the 3M adhesive tape to the base plate and the sensing magnet, then remove the protective film. Stick the transmitter and the sensing magnet onto appropriate positions on the door or window.



3. To ensure proper performance, keep the distance between the transmitter and the sensing magnet less than 8 mm during installation, and avoid areas with strong magnetic fields.



## DEVICE SPECIFICATION

 LoRa band: EU868 / US915 / AU915 / IN865 / RU864 / KR920 / AS923

---

 Sensing Distance:  $\geq 8$  mm

---

 Material: ABS

---

 Battery: 2 x AAA batteries

---

 Dimensions: 70 x 25 x 20 mm (Transmitter), 43 x 12 x 15 mm (Magnet)

---

 Built-in memory: 100 sensing data

---

 Optimal operation and storage conditions: -20 to 60°C, 10% to 90% RH (No condensation)

---

## WARRANTY

This product is covered by a one-year limited warranty from the date of purchase (with valid proof of purchase). During the warranty period, UbiBot will repair defects in materials or workmanship under normal use at no charge. Return shipping to our repair center is the sender's responsibility.

Warranty exclusions:

- Warranty expired.
- Damage caused by misuse, incorrect operation, or failure to follow instructions.
- Accidental or intentional damage (including liquid ingress, impact, deformation, cable damage).
- Normal wear and aging (including casing and cables).
- Unauthorized disassembly or modification.
- Damage due to force majeure (earthquake, fire, flood, lightning, etc.).
- Other damage not caused by manufacturing defects.

V1.0